UV-Nikkor 105mm f/4.5

Nikon

使用説明書 INSTRUCTION MANUAL



目次 ————	CONTENTS———
各部の名称4	NOMENCLATURE
まじめに・・・・・・・5	BEFORE USING THE LENS
紫外線撮影の方法6~10	Light Source
光源6	Filter
フィルター・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・	Photosensitive Materials
感光材料8	Focusing
ピント合わせ9	reproduction ratio
露出10	Depth of field
拡大撮影	Exposure
PART 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1	UV photography at high magnification 25
音率を決めてから撮影するとき	DETERMINING EXPOSURE IN
被写界深度	WISIBLE LIGHT
露出の決め方―可視光線撮影時12~13	Without TTL metering
TTL露出計付きカメラボディの場合12	INFRARED PHOTOGRAPHY 28
TTL露出計付きでない場合13	RECOMMENDED FOCUSING SCREENS 29
13 - 13 TACOM 191 - 13 TACOM 19 TACOM - 10 - 140 TACOM - 10 TACOM - 140 TACOM	LENS CARE
赤外線撮影について14	SPECIFICATIONS
ファインダースクリーン15	DEPTH-OF-FIELD TABLES 32~33
レンズ取扱上の注意16	CLOSE-UP TABLES
生能17	FILTER TRANSMISSION CHART
被写界深度表32	
接写表34	
付属フィルターの分光透過曲線図36	



NOMENCLATURE-

- 1. Depth-of-field indicators
- 2. Aperture scale
- 3. Meter coupling shoe
- 4. Meter coupling ridge
- 5. Aperture-direct-readout scale
- 6. Infrared focusing index
- 7. Aperture indexing post
- 8. EE servo coupling post
- 9. Aperture ring
- 10. Mounting ring
- 11. Focusing ring screw
- 12. Filter holder ring UR-2
- 13. UV transmitting filter
- 14. Aperture/distance index
- 15. Distance scale
- 16. Reproduction ratio scale
- 17. Focusing ring
- 18. Gelatine filter holder AF-1
 (used as UV transmitting filter holder with this lens)

BEFORE USING THE LENS-

Thank you for your kind patronage of Nikon. Before using your new lens, read the following carefully so you get the most out of your lens now and for years to come.

The UV-Nikkor 105mm f/4.5 is specially designed for UV (ultraviolet) photography, and with virtually no variation in the focus position between visible rays and UV rays, it eliminates clumsy focus adjustments.

Special coating is applied to the air-to-glass surface of the lens element to reduce reflection under UV rays.

At all focused distances in every wavelength range, aberration is minimal and distortion is eliminated. Fluorspar is applied to some lens elements to ensure adequate transmission of UV rays.

Of course, ordinary photography can be performed in visible light.

UV PHOTOGRAPHY-

Light Source

A considerable amount of UV radiation is required. As UV rays can be harmful to the human body, however, avoid prolonged use of and direct viewing of UV light sources, and wear protective eyeglasses.

Light sources for UV photography are:

- 1. Sunlight
- 2. Fluorescent blacklights
- 3. Mercury lamps
- 4. Xenon lamps
- 5. Special strobes and flashbulbs
- 6. Others


Filter

Use the supplied UV transmitting filter to eliminate visible and infrared rays. The UV transmitting filter has a transmission band centered on 330nm, and transmits UV rays at wavelengths from 220 to 420nm. (See chart on page 36.)

Filter attachment procedure is:

- 1. Unscrew the filter holder ring UR-2 to open the UR-2.
- 2. Put the filter on the one ring and screw the rings together.
- 3. Screw the assembly into filter holder AF-1.
- 4. Screw the AF-1 into the front of the lens until it clicks.

For ordinary color photography, use a 52mm screwin type L37C or L39 filter to eliminate UV rays.



Photosensitive Materials

Films which may be used in UV photography are:

- 1. For long-wavelength UV photography
 General panchromatic and regular photosensitive
 materials are adequate: Tri-X, Technical Pan 2415,
 Neopan SS, Minicopy film, etc.
- 2. For short-wavelength UV photography
 Special film is required: Kodak Spectroscopic type
 103-O, type 103-F, infrared film*, etc.
 - * When using infrared film and a UV transmitting filter other than the one supplied, check the spectral characteristics of the filter in use. Some UV transmitting filters transmit light in the red and infrared regions at wavelengths of 650nm and longer, and may create overlapping images caused by unwanted wavelengths on the film.

3. Color Film

General color films can be used. The image will appear in a blue monochrome color.

Focusing

Focusing should be performed without a filter. Simply turn the filter holder knob to open the filter holder for focusing, and close it again for shooting.

To focus, first loosen the tightening screw on the focusing ring. To keep the focusing ring from moving, be sure to tighten the screw. The tightening screw makes it difficult to accidentally move the focusing ring, but does not lock it in place. Although it is possible to turn the focusing ring with the screw tightened, do not attempt it.

Thermal characteristics of fluorspar cause a focus shift when temperature changes; check the focus in the viewfinder before shooting.





Focusing on predetermined reproduction ratio

The reproduction ratio scale, inscribed in orange above the distance scale on the focusing ring, enables you to photograph at a predetermined ratio.

For example, to photograph at a reproduction ratio of 1:5, turn the focusing ring until the number "5" is aligned with the distance index, then aim at the subject and adjust your position (closer to, or farther away from the subject) until the image appears sharp on the focusing screen.

The focusing ring tightening screw represents position "4", for one-fourth.



Depth of field

Depth of field can be checked with the color-coded depth-of-field indicators engraved on the lens barrel. The pairs of colored lines correspond to the f-numbers of the same color on the aperture scale. If your camera has a depth-of-field preview function, it is possible to check the depth of field in the viewfinder. (For details, see camera instruction manual).

Depth of field can also be checked by referring to the table on pages 32 and 33.

Exposure

Camera exposure meters cannot be used in UV photography—test shootings are required. The UV sensitivity of the film, the spectral energy distribution of the light source, the spectral transmissivity of the filters, the UV reflection ratio of the subject, etc., should all be considered.

An example of photographic data to take UV photographs of human skin

Light source	Blacklight (BLB) 40W × 4
Filter	UV transmitting filter supplied
Film	Tri-X (D-76, 20°, 7 min.)
Exposure	Approx. 1/125 sec. at f/5.6

UV photography at high magnification

With the optional PN ring, UV photographs at greater than 1:2 reproduction ratio are possible. However, close-up attachment lenses and teleconverters cannot be used in UV photography.

DETERMINING EXPOSURE IN VISIBLE LIGHT-

With built-in TTL metering

Full-aperture exposure measurement can be performed. When used with a close-up attachment such as a PN ring or bellows, see the table at right.

When the lens is mounted in the reverse position, the stop down method should be used.

Camera	Close-up attachment	Exposure measurement
triense V	PN-11	full-aperture
de to eine	PN-1*	stop-down
AI	Bellows/E2 and K rings/ close-up lenses	stop-down
Inchidates)	PN-11	stop-down
	PN-1	full-aperture
Non-AI	Bellows/E2 and K rings/ close-up lenses	stop-down

^{*} Some AI camera bodies with fixed meter coupling lever will not accept the PN-1 ring.

Without TTL metering

At close range, the amount of light reaching the film decreases as the lens-to-film distance increases. When non-TTL measurement is used in such a case, make exposure compensation to prevent underexposure. The table at right gives exposure factors (compensation values) with corresponding exposure increases in f/stops for non-TTL exposure measurement at reproduction ratios of 1:10 or greater.

When you want to limit the aperture compensation to one full f/stop or less, use slower shutter speeds. For example, for a 1:1.2 reproduction ratio, use a shutter speed one step slower and open the lens by 3/4 stop, or use a shutter speed two steps slower stop the lens down by 1/4 stop.

Reproduction ratio	Exposure factor	Exposure increase in f/stop
1:10	1.2	approx. 1/4
1:8	1.3	approx. 1/3
1:6	1.3	approx. 1/3
1:4	1.5	approx. 2/3
1:2	2.2	approx. 11/4
1:1.8*	2.3	approx. 11/3
1:1.6*	2.5	approx. 11/3
1:1.4*	2.8	approx. 1½
1:1.2*	3.2	approx. 13/4
1:1*	3.8	approx. 2

^{*} with PN-11 ring

INFRARED PHOTOGRAPHY—

In infrared photography, it is necessary to make the following adjustment to the focused distance.

- 1. Focus subject.
- 2. Reset the focusing ring to align the focused distance with the infrared focusing index.
- 3. Attach the appropriate optional filter, such as R60, etc., and take the shot.





RECOMMENDED FOCUSING SCREENS

Various interchangeable focusing screens are available for F3- and F2-series cameras to suit any type of lens or picture-taking situation. Those which are recommended for use with your lens are listed below. For screens used with Nikon cameras other than F3- and F2-series cameras (e.g., Nikon FA, FE2, FM2 and FE), refer to the column for F3-series cameras. For the K2, B2 and E2 focusing screens, refer to the columns on the K, B and E screens, respectively. For details, also refer to the specific focusing screen's instruction sheet.

Screen Camera	A/L	В	С	D	E	G1	G2	G3	G4	н	H2	НЗ	H4	J	K/P	М	R	Т	U
F3	0	0		0	0			0	0			0	0	0	0		0	0	0
F2	0	0		0	0			0	0			0	0	0	0	UI.	0	1	07

■ When the Teleconverter TC-14B or TC-14 is attached to this lens, use the following table*:

Screen Camera	A/L	В	С	D	Ε	G1	G2	G3	G4	н	H2	H3	H4	J	K/P	М	R	Т	U
F3	•	0		0	0									0	•		•	•	•
F2	•	0		0	0									0	•		•		

■ When the Teleconverter TC-301 or TC-300 is attached to this lens, use the following table*:

Screen Camera	A/L	В	С	D	E	G1	G2	G3	G4	Н1	H2	НЗ	H4	J	K/P	М	R	Т	U
F3	•	0	On the	0	0			0	0	g	'nÌ	di	to	0	•	111	•	•	•
F2	•	0	HO	0	0			0	0	9	THE STATE OF THE S		1	0	•		•		

- * Teleconverter cannot be used in UV photography.
- O = Excellent focusing
- = Acceptable focusing The image is brilliant from edge to edge, but the center area (range-finder, micro-prism or crosshair) is dim. Focus on the surrounding matte area.
- O = Acceptable focusing Slight vignetting (or moire phenomenon, in the case of the microprism) affects the screen image. The image on the film, however, shows no trace of this.
- = Exposure measurement not possible Lens/screen combination permits only focusing operation.

Blank means inapplicable.

LENS CARE -

- Although you should always keep the lens surfaces clean, rough cleaning must be avoided. Wipe with a soft, clean cotton cloth moistened with alcohol to remove grease or fingerprints from the lens surfaces.
- Keep the lens cap in place whenever the lens is not in use.
- Attach both the front and rear caps when the lens is stored separately.
- To ensure proper fit of the lens when stored in the leather lens case, set the lens' focusing ring to the infinity (∞) setting.

SPECIFICATIONS:

Focal length:

105mm

Maximum aperture:

f/4.5

Lens construction:

6 elements in 6 groups

Picture angle:

23°20'

Distance scale:

Graduated in meters and

feet from 0.48m (1.57 ft.)

to infinity (∞)

Aperture scale:

f/4.5 to f/32 on both stan-

dard and aperture-direct-

readout scales

Reproduction ratio:

Scale provided; 1:10 to 1:2

Diaphragm:

Fully automatic

Exposure measurement: Via full-aperture method;

meter coupling ridge provided for AI cameras and

meter coupling shoe for

non AI cameras

Mount:

Nikon bayonet

Attachment size:

52mm (P = 0.75mm)

Dimensions:

Approx. 68.5mm dia. x 108mm when extended

from lens mounting flange;

approx. 116.5mm long

(overall)

Weight:

Approx. 515g

Accessories

52mm snap-on front lens cap

Rear lens cap LF-1

Gelatine filter holder AF-1

Filter holder ring UR-2

52mm-square UV transmitting filter

52mm dia. screw-in filters


Hard lens case CL-15S

Flexible lens pouch No. 63

Plastic lens case CP-9 Teleconverter TC-14B*

Teleconverter TC-301*

* Cannot be used in UV photography.



被写界深度表/DEPTH-OF-FIELD TABLES-

(m)

撮影距離 Focused	an cotain i	en front les	gans quintifu	被写界深度 Depth of field	tquota à r	f/4.5 6 elements is	erture: ction:	撮影倍率 Reproduction
distance	f/4.5	f/5.6	f/8	f/11	f/16	f/22	f/32	ratio
0.48	0.479-0.481	0.479-0.481	0.479-0.481	0.479-0.481	0.478-0.482	0.478-0.482	0.477-0.484	1/1.98
0.50	0.499-0.501	0.499-0.501	0.499-0.501	0.498-0.502	0.498-0.502	0.497-0.503	0.496-0.505	1/2.23
0.55	0.549-0.551	0.549-0.551	0.548-0.552	0.548-0.553	0.546-0.554	0.545-0.555	0.543-0.557	1/2.8
0.6	0.598-0.602	0.598-0.602	0.597-0.603	0.596-0.604	0.595-0.605	0.593-0.607	0.590-0.611	1/3.33
0.7	0.697-0.703	0.697-0.703	0.695-0.705	0.694-0.706	0.691-0.709	0.688-0.713	0.682-0.719	1/4.35
0.8	0.796-0.804	0.795-0.805	0.793-0.807	0.790-0.810	0.786-0.814	0.781-0.820	0.773-0.830	1/5.34
1	0.992-1.01	0.991-1.01	0.987-1.01	0.982-1.02	0.974-1.03	0.965-1.04	0.950-1.06	1/7.3
1.2	1.19-1.21	1.19-1.22	1.18-1.22	1.17-1.23	1.16-1.25	1.14-1.26	1.12-1.29	1/9.2
1.5	1.48-1.52	1.47-1.53	1.46-1.54	1.45-1.55	1.43-1.58	1.40-1.61	1.37-1.67	1/12.1
2	1.96-2.04	1.95-2.05	1.93-2.08	1.90-2.11	1.86-2.16	1.82-2.23	1.75-2.35	1/16.9
3	2.90-3.11	2.88-3.13	2.83-3.20	2.77-3.28	2.68-3.42	2.57-3.61	2.42-3.99	1/26.4
7	6.42-7.70	6.31-7.87	6.05-8.31	5.76-8.95	5.34-10.25	4.91-12.46	4.33-19.52	1/64.5
00	72.5-∞	59.5-∞	41.7-∞	30.4-∞	21.0-∞	15.3-∞	10.6-∞	1/∞

Focused				Depth of field			of the service of the	Reproduction
distance	f/4.5	f/5.6	f/8	f/11	f/16	f/22	f/32	ratio
(1.57) 1.6	1'6-13/16''- 1'6-13/16''	1'6-13/16''- 1'6-13/16''	1'6-3/4''- 1'6-13/16''	1'6-3/4''- 1'6-7/8''	1'6-3/4''- 1'6-7/8''	1'6-11/16''- 1'6-7/8''	1'6-11/16''- 1'6-15/16''	1/2.0
1.7	1'8-15/16''- 1'9''	1'8-15/16''- 1'9''	1'8-15/16'' 1'9-1/16''	1'8-7/8''- 1'9-1/16''	1'8-7/8''- 1'9-1/8''	1'8-13/16''- 1'9-1/8''	1'8-3/4''- 1'9-1/4''	1/2.6
2.0	1'11-7/8''- 2'1/16''	1'11-7/8''- 2'1/16''	1'11-7/8''- 2'1/16''	1'11-13/16''- 2'1/8"	1'11-3/4''- 2'3/16''	1'11-11/16''- 2'1/4''	1'11-9/16"- 2'7/16"	1/3.4
2.5	2'5-13/16''- 2'6-1/8''	2'5-13/16"- 2'6-1/8"	2'5-3/4''- 2'6-3/16''	2'5-5/8''- 2'6-5/16''	2'5-1/2''- 2'6-7/16''	2'5-5/16''- 2'6-5/8''	2'5-1/16''- 2'6-15/16''	1/5.0
3.0	2'11-3/4''- 3'3/16''	2'11-11/16''- 3'1/4''	2'11-9/16''- 3'3/8''	2'11-7/16''- 3'9/16''	2'11-3/16''- 3'13/16''	2'10-7/8''- 3'1-1/8''	2'10-7/16''- 3'1-11/16''	1/6.5
4.0	3'11-7/16"- 4'1/2"	3'11-3/8''- 4'5/8''	3'11-1/8"- 4'7/8"	3'10-13/16''- 4'1-1/4"	3'10-1/4"- 4'1-13/16"-	3'9-11/16''- 4'2-9/16''	3'8-3/4''- 4'3-7/8''	1/9.4
5.0	4'11-1/8''- 5'7/8''	4'10-15/16''- 5'1-1/16''	4'10-1/2' - 5'1-9/16''	4'9-15/16''- 5'2-3/16''	4'9-1/16''- 5'3-1/4''	4'8-1/16''- 5'4-9/16''	4'6-1/2''- 5'6-15/16''	1/12.3
7.0	6'10-1/16''- 7'1-15/16''	6'9-11/16''- 7'2-3/8''	6'8-3/4''- 7'3-1/2''	6'7-5/8''- 7'4-15/16''	6'5-13/16''- 7'7-3/8''	6'3-11/16''- 7'10-9/16''	6'9/16''- 8'4-3/8''	1/18.2
10.0	9'7-7/8''- 10'4''	9'7"-10'5"	9'5''-10'7''	9'2-5/8"- 10'11"	8'10-13/16''- 11'5''	8'6-11/16''- 12'1''	8'1/2"- 13'4"	1/26.9
20.0	18'6"-21'8"	18'3"-22'1"	17'7"-23'1"	16'10''-24'7''	15'9''-27'6''	14'7''-32'1"	13'-44'8"	1/55.9
∞	238′-∞	195′-∞	136′-∞	99′-∞	68′-∞	50′-∞	34′-∞	1/∞

4.000		(正方向 in normal posi	tion		ズ逆向き is in reverse posi	tion
使用器具 Close-up attachment	撮影倍率 Reproduction ratio	被写界面積 Subject field	撮影距離 Focused distance	撮影倍率 Reproduction ratio	被写界面積 Subject field	撮影距離 Focused distance
クローズアップレンズNo.0 Close-Up Lens No. 0	1/14-1/1.7	32.8 × 49.2- 4.0 × 6.1	159-43.9	3-11-2-315		141-8-11
クローズアップレンズNo.1 Close-Up Lens No. 1	1/6.5-1/1.4	15.5 × 23.2- 3.5 × 5.2	84.5-40.9	1839 2083	(J.E.C) = 1.581	NE [14] 2
クローズアップレンズNo.2 Close-Up Lens No. 2	1/3.2-1/1.1	7.8 × 11.6- 2.7 × 4.0	50.4-36.6	-23,	-	111-11
クローズアップレンズNo.3T Close-Up Lens No. 3T	1/6.4-1/1.4	15.3 × 22.9- 3.4 × 5.1	82.9-40.5	1001 - 2001	MITTO FORM	AE-11731S
クローズアップレンズNo.4T Close-Up Lens No. 4T	1/3.3-1/1.1	7.8 × 11.7- 2.7 × 4.0	50.1-36.3		10 - HOL	3182
EZリング E2 Ring	1/7.5-1/1.6	18.0 × 27.1- 3.8 × 5.7	102.3-45.1		8 4	1512
Kリング K Ring Set	1/18.1-1/1.1	43.5 × 65.3- 2.5 × 3.8	213.2-42.9	81 - 81	155 m 35	81-
PKリング PK-Series Rings	1/13.2-1.0	31.6 × 47.3- 2.5 × 3.7	161.0-42.9	- 1	208 - 193	116-12
PNリング PN Ring	1/2.0-1.0	4.8 × 7.2- 2.4 × 3.6	48.1-42.9	Pet 12 48 01	-	811-1 211-5
ベローズアタッチメントPB-4, PB-5 Bellows Focusing Attachment PB-4, PB-5	1/2.4-1.8	5.9 × 8.8- 1.4 × 2.0	51.9-46.3	1/3.5-1.6	8.3 × 12.5 – 1.5 × 2.2	61.4-45.5
ベローズアタッチメントPB-6 Bellows Focusing Attachment PB-6	1/2.2-2.0	5.3 × 7.9- 1.2 × 1.8	49.7-48.0	1/5.3-1/1.3	12.6 × 18.9- 3.1 × 4.6	79.2-43.5
エクステンションベローズPB-6E Extension Bellows PB-6E	1/2.2-4.2	5.3 × 7.9- 0.58 × 0.86	49.7-68.2	1/5.3-3.0	12.6 × 18.9- 0.81 × 1.2	79.2-56.6
複写装置PF-2, PF-3, PF-4 Reprocopy Outfit PF-2, PF-3, PF-4	1/5.9-1/2	14.1 × 21.1- 4.8 × 7.2	85.3-48.0	_	-	-

^{*}Kリングのはじめの数値はKリング I 個使用のとき、あとの数値はKI-K5リングを連結したときのものです。

^{**}PKリングのはじめの数値はPK-IリングまたはPK-IIリング I 個使用のとき、あとの数値はPK-I~PK-3またはPK-II~PK-13リングを連結したときのも のです。

^{***}複写装置PF-2、PF-3、PF-4はレンズ単体で使用したとき、複写台の載物面上の撮影可能範囲を示します。

^{*} The first values are for the K1 ring used alone and the second ones for all five rings together.

** The first values are for the PK-1 or PK-11 ring used alone and the second ones for three (PK-1-PK-3 or PK-11-PK-13) used together.

*** The figures shown here represent the ranges obtained with the subject on the baseplate, using the lens without any close-up attachment.


(in.)

	Lens	s in normal position	n	Lens	in reverse positio	n
Close-up attachment	Reproduction ratio	Subject field	Focused distance	Reproduction ratio	Subject field	Focused distance
Close-Up Lens No. 0	1/14-1/1.7	12.9 × 19.4- 1.6 × 2.4	62.6-17.3	-/	1-	-
Close-Up Lens No. 1	1/6.5-1/1.4	6.1 × 9.1- 1.4 × 2.0	33.3-16.1	H +		-
Close-Up Lens No. 2	1/3.2-1/1.1	3.1 × 4.6- 1.1 × 1.6	19.8-14.4	-	-	
Close-Up Lens No. 3T	1/6.4-1/1.4	6.0 × 9.0- 1.3 × 2.0	32.6-15.9	4-	-	-
Close-Up Lens No. 4T	1/3.3-1/1.1	3.1 × 4.6- 1.1 × 1.6	19.7-14.3	-	-	_
E2 Ring	1/7.5-1/1.6	7.1 × 10.7 – 1.5 × 2.2	40.3-17.8	-	-	-10-
K Ring Set	1/18.1-1/1.1	17.1 × 25.7- 1.0 × 1.5	83.9-16.9	-	-	-
PK-Series Ring	1/13.2-1.0	12.4 × 18.6- 1.0 × 1.5	63.4-16.9	-	-	122
PN Ring	1/2.0-1.0	1.9 × 2.8- 0.9 × 1.4	18.9-16.9	-	-	0.5
Bellows Focusing Attachment PB-4, PB-5	1/2.4-1.8	2.3 × 3.5- 0.54 × .081	20.4-18.2	1/3.5-1.6	3.3 × 4.9 – 0.58 × 0.87	24.2-17.9
Bellows Focusing Attachment PB-6	1/2.2-2.0	2.1 × 3.1- 0.48 × 0.72	19.6-18.9	1/5.3-1/1.3	5.0 × 7.5 – 1.2 × 1.8	31.2-17.1
Extension Bellows PB-6E	1/2.2-4.2	2.1 × 3.1- 0.23 × 0.34	19.6-26.8	1/5.3-3.0	5.0 × 7.5- 0.32 × 0.48	31.2-22.3
Reprocopy Outfit PF-2, PF-3, PF-4	1/5.9-1/2	5.6 × 8.3- 1.9 × 2.8	33.6-18.9	-	-	- 1

^{*} The first values are for the K1 ring used alone and the second ones for all five rings together.

** The first values are for the PK-1 or PK-11 ring used alone and the second ones for three (PK1-PK-3 or PK-11-PK-13) used together.

*** The figures shown here represent the ranges obtained with the subject on the baseplate, using the lens without any close-up attachment.





No reproduction in any form of this booklet, in whole or in part (except for brief quotation in critical articles or reviews), may be made without written authorization from Nippon Kogaku K.K.

NIPPON KOGAKU K.K.

Fuji Bldg., 2-3, Marunouchi 3-chome, Chiyoda-ku, Tokyo 100, Japan **Phone:** 81-3-214-5311 **Telex:** J22601 (NIKON) **Fax:** 81-3-201-5856

Printed in Japan 8&015-B07